## Pre-operational safety checks for XRF device

## When are safety checks required?

Safety checks are required after installing accessory components tortage Exmitting Devices (XEDs) and after conducting maintenance on the equipment.

## Safety Checks Should Ensure:

- x The proper functioning of all protective and safetyvices.
- x The proper assembly and functioning of all radiation shields, beam ports, accessories and fittings.
- x That ambient radiation levels are within the permissible regulatory limit (~4.3  $\mu$ Sv/hr at 5 cm from all external surfaces of the equipment) by using an appropriate smootery.
- x That any safety bypass procedures are of the orthiene actuation type and reverte a failsafe situation at startup time of the Xray generator.