



Ensure oil lubricated vacuum pumps are equipped with an oil mist filter and are exhausted to the outside (e.g. through a fume hood)

#### Recommendations

- Always direct vacuum pump exhaust into a fume hood or other ventilation to the outside.
- Always equip oil